Waste Oil Evacuation System

WOP-16MP.16QC.EHL2



EHL-2 Overfill Protection System



High Level Alarm/Pump Shut Down

The EHL-2 turns on a warning light and sounds a buzzer when the level in the waste oil tank reaches the "LOW" level point. The light will remain on until the level in the tank is brought down below the "LOW" level set point. The buzzer can be muted.

When the level in the tank reaches the "LOW-LOW" level point, the system turns on a waring light, sounds the buzzer and shuts the pump down. The warning light will stay on and the pump will remain inoperable until the level in the tank is brought down. In both "LOW" and 'LOW-LOW" conditions, the buzzer can be muted.



Wiring Connection Wiring connection of the twin float assembly to the EHL-2 panel requires a 4 conductor jacketed electrical cable, 16AWG OR 18AWG. The cable is ordered separately according to the length of cable required.

When ordering cable for up to 200 ft., use part number WR-184



The EHL-2 comes with a 10 ft.